

[illegible]

右引き手	左引き手

[illegible]

振れ止め金具取り付け位置 S=1/2

Technical drawing showing the installation positions for anti-rattle fasteners (振れ止め金具) on a window frame. The drawing includes dimensions for the frame and the placement of fasteners for the bed (床付け用) and sash (扉付け用).

Dimensions and labels:

- Overall width: 195
- Bed fastener (床付け用) position: 67 (from left edge), 6.5 (from vertical center line), 30 (from vertical center line), 8 (from vertical center line), 30 (from vertical center line), 8 (from vertical center line), 30 (from vertical center line).
- Sash fastener (扉付け用) position: 5 (from vertical center line), 18 (from vertical center line).
- Frame height: 18, 20
- Fastener height: 4.5, 6, 12, 10.5
- Labels: 中方立 (Middle frame), 引き戸 (Sliding door), フロアー (Floor), 振れ止め金具 (床付け用) (Anti-rattle fastener (bed attachment)), 振れ止め金具 (扉付け用) (Anti-rattle fastener (sash attachment)).

平面図

小壁

振れ止め金具 (床用)

中方立

30

19

3 15 5

18